

CV: Attenuator for the control voltage input "CV In".

Gain: Manual gain control (continuous level setting). Controller position and control voltage ("CV In") are always summed up.

The **lin. / exp.** switch can be used to switch between linear and exponential characteristics for the amplification.

