

Man: Manual controller for the positive or negative amplification of the signal present at the "In" input . When the controller is in the "12 o'clock" position (middle position), the input signal is completely suppressed. The LED shows the position of the controller (or the applied control voltage).

CV: Attenuator for the control voltage input "CV".

The two controllers below have the same functions for the second sub-module.

