



**CV1:** Control voltage input for modulating the frequency of the LFO (without attenuator).

**CV2:** Control voltage input for modulating the frequency of the LFO (with attenuator "CV2").