

**0° SINE:** Output for the sine signal. The two LEDs next to the output show the current positive or negative voltage. Amplitude at all outputs approx. +/- 2.5 V.

**90° COSINE:** Output for a 90 degree phase-shifted sine signal (cosine).

**180° SINE (inverted):** Output for a 180 degree phase-shifted sine signal (inverted sine).

**270° COSINE (inverted):** Output for a 270 degree phase-shifted sine signal (inverted cosine).

