

Trigger Out 1-8: Separate trigger outputs for each of the 8 tracks of the sequencer. An active trigger is indicated with an LED to the left of the output jack.

