

USB: USB input for Midi data from USB host (e.g. a computer with appropriate DAW software) to control the A-100 system.

Midi In: Midi DIN input for Midi data from a sequencer or master keyboard to control the A-100 system.

