

Midi In: Midi DIN input for Midi data from a sequencer or master keyboard to generate clock and transport signals for the A-100 system.

USB: USB input for Midi data from USB host (e.g. a computer with appropriate DAW software) to generate clock and transport signals for the A-100 system.

Wait: Trigger input to stop a connected sequencer such as the A-155 via the "Sta" and "Stp" outputs with the exact beat or to start it again later with the same beat (for details, see the description of the "Wait" button).

