

Ext. Start: Trigger input to start the sequencer. The function is analogous to the A-155, but here it can control up to two A-155s at the same time.

Ext. Stop: Trigger input to start the sequencer. The function is analogous to the A-155, but here it can control up to two A-155s at the same time.

Ext. Reset: Trigger input to start the sequencer. The function differs somewhat from the A-155: With the A-155 the jump to the first stage is immediate, with the A-154 the next clock signal is awaited.

Ext. Clock: Trigger input for an external clock signal. The switching socket interrupts the internal clock and replaces it with the external signal.

Ext. A-154 Master: Gate input to control a connected A-155 again through its internal control unit. Caution: If two A-155s are connected, the internal control unit of the *first* A-155 takes over *both* sequencers (independent operation of the two sequencers is not possible).

